## 1.RS-232 Command:

Baudrate: 115200 Data width: 8bit Parity: none Stop: 2bit

#### Port switch command package length is 13byte:

For example: Set output 1 form input 2 command: A5 5B 02 03 02 00 01 00 00 00 00 00 F8

# Port switch query command package length is 13byte:

This is a query command which mean you must send query package and then receive an answer. For example: Query output A input port (1~8) Send package: A5 5B 02 01 01 00 00 00 00 00 00 00 FC Receive package: A5 5B 02 01 01 00 01 00 00 00 00 FB The red 01 mean the output port number, it should be 1~8. The blue 01 mean the input port number, it should be 1~8.

# Edid set command package length is 13byte:

[0xa5+0x5b+0x03+0x02+Edid index(1~15)+0x00+input port(1~8)+0x00+0x00+0x00+0x00+0x00+checksum]

# Edid query command package length is 13byte:

This is a query command which mean you must send query package and then receive an answer. For example: Query input 1 Edid index (1~15) Send package: A5 5B 01 0C 01 00 00 00 00 00 00 00 checksum Receive package: A5 5B 01 0C 01 00 01 00 00 00 00 00 checksum The red 01 mean the input port number, it should be 1~8. The blue 01 mean the Edid index number, it should be 1~15.

### Edid index list:

1080p,Stereo Audio 2.0	= 1
1080p,Dolby/DTS 5.1	= 2
1080p,HD Audio 7.1	= 3
1080i,Stereo Audio 2.0	= 4
1080i,Dolby/DTS 5.1	= 5

1080i,HD Audio 7.1	= 6
3D,Stereo Audio 2.0	= 7
3D,Dolby/DTS 5.1	= 8
3D,HD Audio 7.1	= 9
4K2K30,Stereo Audio 2.0	= 10
4K2K30,Dolby/DTS 5.1	= 11
4K2K30,HD Audio 7.1	= 12
4K2K60,Stereo Audio 2.0	= 13
4K2K60,Dolby/DTS 5.1	= 14
4K2K60,HD Audio 7.1	= 15

### Edid copy command package length is 13byte:

[0xa5+0x5b+0x03+0x04+**output port (1~8)**+0x00+**input port(1~8)**+0x00+0x00+0x00+0x00+0x00+0x00+**checksum**] Means: copy output port X edid to input port X

# Output HDP status query command package is 13byte:

This is a query command which mean you must send query package and then receive an answer. For example: Query output 1(1~8) HPD status Send package: A5 5B 01 05 01 00 00 00 00 00 00 00 F9 Receive package: A5 5B 01 05 01 00 FF 00 00 00 00 FA The red 01 mean the output port number, it should be 1~8. The blue FF mean this port's HPD is LOW, if 00 mean HIGH.

# Input port status query command package is 13byte:

This is a query command which mean you must send query package and then receive an answer. For example: Query input 1(1~8) status Send package: A5 5B 01 04 01 00 00 00 00 00 00 00 FA Receive package: A5 5B 01 04 01 00 FF 00 00 00 00 00 FB The red 01 mean the input port number, it should be 1~8. The blue FF mean this port is plug out, if 00 mean plug in.

## Beep on/off query command package is 13byte:

This is a query command which mean you must send query package and then receive an answer. For example: Send package: A5 5B 01 0B 00 00 00 00 00 00 00 00 F4 Receive package: A5 5B 01 0B 00 00 FF 00 00 00 00 F5 The blue FF mean Beep off, if 00 mean Beep on.

# Device and software version query command package is 13byte:

This is a query command which mean you must send query package and then receive an answer. For example:

Send package:	A5 5B 01 01 00 00 00 00 00 00 00 00 00 checksum		
Receive package:	A5 5B 01 01 01 00 00 00 00 00 00 00 checksum		
The blue 01 mean HDMI Matrix.			

Device List:	
HDMI Matrix	= 1
HDBT Matrix	= 2
HDMI+HDBT Matrix	= 3

For example:

Send package:	A5 5B 01 02 00 00 00 00 00 00 00 00 00 checksum		
Receive package:	A5 5B 01 02 08 00 08 00 00 00 00 00 checksum		
The blue 08 mean 8 inputs.			
The red 08 mean 8 outputs.			

For example:

Send package:A5 5B 01 03 00 00 00 00 00 00 00 00 00 00 00 checksumReceive package:A5 5B 01 03 01 00 22 00 00 00 00 00 checksumThe blue 01 mean the integer part is 1.The red 22 mean the decimal part is 34.

Device: HDMI Matrix 8x8 Version: 1.34

**Factory reset command package length is 13byte:** A5 5B 08 0A 00 00 00 00 00 00 00 00 EE